

2005-2015 Tacoma 4wd LCA Skids



Install Lower Control Arm Skids using supplied hardware.
3/8" x 3.5" Carriage Bolt at the rear.
3/8" x 3" Carriage Bolt at the front.
5/16" x 2.5" Buttonhead bolt w/washer at the outer hole.

Note: some aftermarket (stock) replacement arms may require drilling one or more holes